



Update the Nano-Spot running Pi-Star

You must use Putty to gain access to the Nano-Spot!

Make the disk RW

Type: Sudo -i

Type: mount -o remount,rw /

Stop the services

Type: systemctl stop pistar-watchdog.timer

Wait

Type: systemctl stop pistar-watchdog.service

Wait

Type: systemctl stop mmdvmhost.timer

Wait

Type: systemctl stop mmdvmhost.service

Upgrade the system

Type: sudo pistar-upgrade

Wait

Type: sudo pistar-update

Wait

Type: sudo reboot